

**“ STANLEY ”**  
**SURVEYORS' ANEROID BAROMETERS**  
**WITH METRIC SCALE**

<b>A1342</b>	3 in.	reading by vernier to 1 metre up to 2,000 metres
<b>A1343</b>	„ „	1 metre „ 3,000 metres
<b>A1344</b>	„ „	1 metre „ 5,000 metres
<b>A1345</b>	„ „	2 metres „ 6,000 metres
<b>A1346</b>	5 in.	reading by vernier to $\frac{1}{2}$ metre up to 1,000 metres
<b>A1347</b>	„ „	$\frac{1}{2}$ metre „ 2,000 metres
<b>A1348</b>	„ „	1 metre „ 3,000 metres
<b>A1349</b>	„ „	1 metre „ 5,000 metres
<b>A1350</b>	„ „	1 metre „ 6,000 metres

**“ STANLEY ” MINING ANEROIDS**

- A1352** 3 in. with Altitude Scale arranged for mining 4,000 ft. above and 2,000 ft. below sea level, reading by vernier to 2 ft.
- A1353** 5 in. ditto, reading to 1 ft.
- A1354** 3 in. with Altitude Scale arranged for mining 1,500 metres above and 800 metres below sea level, reading by vernier to 1 metre.
- A1355** 5 in. ditto, reading to  $\frac{1}{2}$  metre.

*Quote Stanley's 'A' Catalogue*